Canvas Wall Tent Instructions

1. Choose flat location clear of rocks and debris. Ensure the space is not directly under trees to allow safe area for stove pipe if wood stove is used.
2. Lay green vinyl tent floor on ground in desired tent location.
3. Place angles on floor, arranged to set-up. 3-way angles go on the ends, 4-way angles are the middle sections. Unless the angles are marked specifically "Ridge only" (only 10'X12' tent) they are the same angle for the eves, ridge, and rafters.
4. Tent poles - Legs have the rubber piece at the bottom. Ridges and Eves (horizontal runners looking straight at tent) are marked "Ridge/Eve". Rafters run between the eves and the ridge to make the peak. They will be marked "Rafter".
5. Assemble the frame except for legs on one side of the tent (allows for easier time place tent on frame).
6. Unzip the door and drape tent over frame, keeping in mind your desired door and stove jack orientation. On the side without legs, fold the sidewall up on the roof
7. Drape white rain fly over tent at this stage and ensure stove jack flaps are rolled back and secured if wood stove is to be used.
8. With assistance, lift the side eve without legs up and have another person install the legs in the angles. Gently adjust tent over frame.
9. Fold perimeter sod cloth inwards and adjust green vinyl floor over. We like to position the legs over the floor to hold in place.
10. Install smaller stakes to perimeter tent loops to hold sidewalls down.
11. Tie adjustable guy lines to tent and fly eyelets with a simple knot. Use larger stakes driven in at 45 degree angle away from tent at a distance that keeps the guy line at the same angle as the roof. (Not all guy lines will be used and they are adjustable with the metal clasp. Some prefer to use lines on every other eyelet or alternatively two on every corner. Just make sure every corner is tied and you use enough to keep the tent sturdy for the conditions.)
12. Secure guy line loops around stakes and tension appropriately. We use one stake for two guy lines (1 tent line & 1 fly line).
13. If using the wood stove - position fire mat over floor area to be used. Remove all contents from inside stove. Use two people to carry stove and set on fire mat. Screw in legs and position so the stove pipe hole is lined up with the stove pipe jack on the tent.
14. Stove pipe is telescoping. Place the narrowest section into the wood stove hole and press firmly into place. Make sure the damper is installed appropriately so that it can be manipulated with the handle.
15. Fit the remaining stove pipe pieces together outside of the tent, including the spark arrestor cap on top. Have another person push this section through the stove jack hole on the tent from

the outside. Reposition stove as necessary so stove pipe is aligned and tightly fitted. Make sure no tent fly material is touching the stove pipe and nothing is placed near the stove. The stove has a shelf that can be installed on either side. This gets hot and should only be used to set a pot of water on if used at all.

16. If Stove rocks in place- then the ground is not flat enough. Shim the legs accordingly to ensure it does not rock or move. Do not use the stove if it is not secure in place. When using, the door latch and dampers get extremely hot. Use a potholder to open and close. Please use caution around the stove. You are responsible for its use and care. DO not leave stove running and unattended. Only burn clean and dry wood. A little goes a long way. This stove heats a tent extremely well.

Take-down

Please keep tent clean by dismantling and folding on top of floor

1. Unzip door, clean sod cloth around bottom of tent free of dirt and debris.
2. Disassemble wood stove, if used, in the reverse manner it was set-up. Stow stove items back inside of the stove and remove from tent *Do not light a fire on the last day in the stove to ensure it can be handled safe and cool for take-down.*
3. Remove tent stakes from perimeter tent loops.
4. Fold side walls in towards tent
5. Remove guy lines from fly and tent, fold and stow away fly. Place all stakes and lines used back in the tote.
6. Take down tent in reverse order of set-up, removing one Side of legs, then the other. Roll tent together to keep it over the floor as you remove poles and angles. Stow angles and poles in the manner they were provided.
7. Fold / roll tent on floor to keep it clean. Don't worry about a perfect fold or roll as we will need to wash it off, air dry, and fold for storage after the rental. Please ensure all items that were included are returned.
8. Return tent package as previously arranged for or give us a call to coordinate return. 509-355-3740.

Renting a wall tent is helpful to not deal with the maintenance, cleaning, storage, and upfront cost. But if a wall tent is something you want to own, let us know. We have used ones for sale occasionally but can also point you in the right direction for where to go to get your own set-up!

Thank you for choosing us to supply your basecamp rental.

-Logan (owner)